

Decorative Fireplaces

Instructions for assembly and use

Please read the instructions below carefully and observe the guidelines closely.

Installation of the decorative fireplace

To attach the decorative fireplace to the wall, use the screws supplied. The correct position of the screws for hanging up the decorative fireplace is determined by the enclosed drawing (drilling guide). You can transfer the corresponding sizes to the wall. You must ensure that the fireplace is attached sufficiently sturdily to the wall. Additional protective measures must be taken for walls and floors with a U-load of less than 0.4 W/m²K. The fuel box can be completely removed from the decorative fireplace. Always be extremely careful when removing the fuel box. It may only be removed from the decorative fireplace if it is cold.

Important!

- The decorative fireplace can only be hung on walls without any flammable materials (wallpaper, wood or other wall covering). Please test that the screws supplied are suitable for use in the wall in question.
- Make sure there is sufficient air supply without draughts. Inside, the decorative fireplace may only be
 installed in places where there are no cross-currents of air. The following minimum rooms sizes should be
 observed when installing the fireplace.

| Type Cubico BL | | |
|------------------------|-------------------|---|
| | | |
| Minimum room size (m³) | Ventilation (1/h) | Remarks |
| 261 | 0.2 | Ventilation rate as a result of insulation failures in the building |
| 87 | 0.6 | Customary ventilation rate in closed buildings with |
| | | standard ventilation habits of the user |
| 52 | 1 | Complete change of air of the installation room within |
| | | one hour |

| Type Riviera DU(GL) | | |
|------------------------|-------------------|---|
| Minimum room size (m³) | Ventilation (1/h) | Remarks |
| 359 | 0.2 | Ventilation rate as a result of insulation failures in the building |
| 120 | 0.6 | Customary ventilation rate in closed buildings with |
| | | standard ventilation habits of the user |
| 72 | 1 | Complete change of air of the installation room within |
| | | one hour |

As a rough guideline, the following ventilation rates are given in accordance with 1*:

| 7 5 a roagh gaideine, the following vertiliation rates are given in accordance with 1. | | |
|--|---------------------------|--|
| Ventilation (1/h) | Remarks | |
| 0 0.5 | Windows and doors closed | |
| 0.3 1.5 | Windows ajar, no shutters | |
| 510 | Windows half open | |

^{1*} Rechnagel, Sprenger, Schrameck: *Heating + Air Conditioning* (technical literature)

- Only place the decorative fireplace where children and/or pets do not have direct access to it.
- Ensure that furniture, curtains or other flammable materials are at least one meter away from the decorative fireplace. This minimum distance also applies for people and animals, to prevent movements that can affect the flames.
- Do not cover the decorative fireplace. Do not place any flammable materials or clothing on the decorative fireplace.
- Only bioalcohol (96% ethanol) is suitable for use in the decorative fireplace. Never burn other materials in the decorative fireplace.
- <u>Safretti delivers its own unique fuel.</u> Ask about the possibilities or consult <u>www.safretti.com</u>.
- The decorative fireplace is a fireplace meant for decorative purposes only.
- The decorative fireplace can be placed in rooms inside and outside, but we do not recommend that you place it in bedrooms.

Using the decorative fireplace

The proper functioning of the decorative fireplace can only be guaranteed if the aforementioned fuel is used.

Placing the fuel box

A removable fuel box has been placed in the decorative fireplace which you must remove before filling. Always exercise the necessary caution when removing the fuel box. The fuel box may only be filled <u>outside</u> the decorative fireplace. For optimum functioning the fuel box should be completely filled. Do not spill any fuel! If fuel is spilled, first clean up the spilled fuel, for example with paper towels, before lighting the fire. Place the fuel box in the decorative fireplace and make sure that it is firmly in place.

Lighting the decorative fireplace

Check that the fuel box has been put back into the decorative fireplace correctly. Do not place anything on the fire such as ceramic logs because this immediately leads to soot being formed. Always light the decorative fireplace with the specially provided Safretti lighter. The fuel should be at room temperature when being used. It can take a while for the flames to reach their full height, depending on the temperature of the fuel. In certain circumstances, it can occur that the burner does not work straight away. Please wait sufficiently long before trying to light it again.

Important!

- Never light the fuel in a fuel box that is not in place!
- Only light the burner if it is completely filled with fuel.
- Do not smoke whilst filling the fuel box.
- When lighting it, always keep sufficient distance from the casing.
- Never top up a fuel box whilst it is still warm or whilst the decorative fireplace is still burning.
- The fuel box should always be (re)filled outside the decorative fireplace.
- The casing of the decorative fireplace is made of steel, aluminium or stainless steel. These elements can get hot when the fuel is lit. Avoid physical contact with the steel, aluminium or stainless steel elements.
- Do not place any objects on the decorative fireplace.

Extinguishing the decorative fireplace

To extinguish the fire in the decorative fireplace, carefully place the lid provided on the fuel box. Be careful: the fuel box may be hot! Placing the lid on the fuel box shuts off the air supply and therefore the flames go out by themselves.

Fuel

The fuel is a (highly)inflammable product. The packaging should always be kept away from sources of heat and ignition. Always keep the fuel in a dark, dry and cool place. Never place it in full sunlight. Keep the fuel out of reach of children. It is not suitable for internal use. If fuel is swallowed, contact the anti-poison centre or seek expert medical advice.

Important!

- Never mix the fuel with other fuels.
- Never fan or blow out the fire (danger of flames forming or getting burned!).
- Always follow the instructions on the label of the fuel packaging.
- The fuel is a (highly) inflammable product.
- Avoid contact with the eyes and skin.
- People with respiratory complaints are advised not to sit in rooms with a decorative fireplace.
- Never leave the fire unattended! Never leave children alone in the room whilst the decorative fireplace is
 on.
- Try to avoid draughts, they can lead to soot forming.

Cleaning the fuel box

When the contents of the fuel box have completely burned up, wait until the fuel box is completely cold before removing the fuel box from the decorative fireplace to remove any remnants of the fuel. After use you can clean the fuel box by placing it in soapy water for about half an hour, if necessary cleaning it with a brush and rinsing with water. When the fuel box is dry it can be refilled with fuel.

We wish you lots of pleasurable moments with the Safretti decorative fireplace.

For more information see: www.safretti.com.

